



NOTE:

Use 2 ounces antifreeze glycol fluid in the drip pot to "dry" the gas.

Blow out the used fluid by using the drain plug and replace with new fluid.

The drip pot may collect the fluids without glycol.